Lighting Control

To switch the lights on in the room the rocker switch needs to be pressed and released once.

To switch the lights off the rocker switch needs to be pressed and released once more.

If you would like to dim the lights in the room, once the lights are on, hold down the rocker switch until the light has dimmed to the desired level, then release it.

To brighten the lights, hold down the rocker switch until the light has increased to the desired level, then release it.

The lights will switch off if there is no movement detected in the room for a period of 30 minutes